

sintol sachets 6g

CHLORINE DISINFECTANT-CLEANER



Uses

For the disinfection of floors and surfaces in high-risk areas.

Application

Apply to surfaces with a cloth, mop or mechanical spray device so as to thoroughly wet surfaces. For heavily soiled areas, a preliminary cleaning is required. A fresh solution should be prepared daily or when the use-solution becomes visibly dirty. For general disinfection, allow a contact time of 30-60 seconds and for virus disinfection, allow a contact time of 5-10 minutes.

Dilution

Purpose	Sachets	Dilution in water	Chlorine strength ppm
General use: floors, walls, surfaces and food processing equipment	1 x 6g	9lt	250
Cleaning and sanitizing fridges and cold rooms	2 x 6g	9lt	500
Ablution blocks, showers, baths and toilets	1 x 6g	9lt	250
Terminal disinfection of infected areas: beds, lockers, cots, plastic covers of pillows and mattresses	4 x 6g	9lt	1000
Incubators	1 x 6g	4.5lt	500
Bottles and teats: after cleaning, soak in solution for 30 minutes	1 x 6g	20lt	112
Instruments: washing. Avoid prolonged immersion procedures	1 x 6g	4.5lt	500
Infected linen and sheepskins, soak for 30 minutes	2 x 6g	9lt	500
Spills: blood and body fluids, faeces and urine	5 x 6g	1lt	10 000
Viruses: including AIDS, Hepatitis B and Avian H5N1	5 x 6g	1lt	10 000
Laboratory use: Low risk	2 x 6g	4.5lt	1 000
Laboratory use: High risk	2 x 6g	1.8lt	2 500
Kitchen floors, walls and equipment, meat cutting blocks	1 x 6g	9lt	250
Washing salads, fruit etc	1 x 6g	25lt	100

sintol sachets 6g

CHLORINE DISINFECTANT-CLEANER



Supplies

6g (100) - 06610

Notes

Do not mix with detergents. Use cold or warm (not hot) water for dilution. Mix well until all solids have been dissolved and solution is clear. Prolonged soaking of instruments should be avoided.

Compounds

- 35% Sodium dichloroisocyanurate (SDIC)

Storage

Store away from foodstuffs. Protect from sunlight and do not expose to temperatures exceeding 50°C.

Technical specifications

Description	Result
Colour	White granular powder
Odour	Chlorine
pH in dilution (1%)	9.5 – 10.5
Solubility with water	Completely soluble
Flammability	Non-flammable
Area of application	Industrial, domestic, institutional & food
Spectrum of activity	Bactericidal

Specifications and details are subject to change without prior notice

Certifications



SANS1853: Disinfectants, detergent-disinfectants and antiseptics for use in the food industry



NRCS Registration: NRCS/8054/237691/991

Industroclean (Pty) Ltd

Tel: +27 11 801 4600

Mail: info@industroclean.co.za

www.industroclean.co.za

IS-BO0007

sintol sachets 6g

CHLORINE DISINFECTANT-CLEANER



Test organisms

Bacteria	Viruses	Spores
Acinetobacter	Influenza A (Brazil)	Bacillus (anthrax)
Campylobacteri jejeuni	Influenza A2 (Aichi)	Bacillus (cereus)
Clostridium bifermentans	Influenza A2 (Hong Kong)	Bacillus (stearothermophilus)
Clostridium difficia	Legionnaires Disease	Bacillus (subtilis)
Clostridium tetani	Meningitis	Fungus
Escherichia coli	Oncovirus	Aspergillus fumigatus
Klebsiella pneumonia	Orthopox virus	Aspergillus niger
Listeria monocytogenes	Papillomas (warts)	Penicillium curysogerm
Mycobacterium leprosy	Parainfluenza	Trichophyton gypseum (ring worm)
Mycobacterium tuberculosis	Parainfluenza 3	Saccharomyces cerevisiae
Neisseria meningitides	Paramyxo virus (measles)	Microsporum gypseum (skin & hair fungus)
Proteus vulgaris mirabilis	Paramyxovirus	Mucor hiemalis (lung)
Pseudomonas aeruginosa	Paramyxovirus (mumps)	Candida Albicans (thrush)
Salmonella entertides	Parvovirus (canine)	
Salmonella choleraesuis (cholera)	Pneumonitis (feline)	
Salmonella typhi (typhoid)	Polio virus	
Serratia marcescens	Polyoma virus	
Staphylococcus aureus	Pseudorabies virus	
Staphylococcus epidermidis	Reovirus	
Streptococcus faecalis	Reovirus / Rotavirus (Infant gastroenteritis)	
Streptococcus pneumonia	Rhino virus	
Viruses	Rubella (German Measles)	
Adenovirus	Togaviridae (Yellow fever)	
Akabane	Varicella	
Arbovirus		
Arenavirus		
Bronchitis		
Bunyavirus (rift valley fever)		
Corona virus (common cold)		
Coxsackie virus		
Cytomegalovirus		
Echovirus		
Encephalitis		
Hepatitis A, B, C		
Herpes Simplex – Type 1, Type 2		
HV – Type 1, 2		

Industroclean (Pty) Ltd

Tel: +27 11 801 4600

Mail: info@industroclean.co.za

www.industroclean.co.za

IS-BO0007